

M-S Cash Drawer Corporation

ASCII Timing Chart for KSI interface (part 2, characters 64 - 127)

Decimal	ASCII Character	Switch						
		1	2	3	4	5	6	7
64	@	0	0	0	0	0	0	1
65	A	1	0	0	0	0	0	1
66	B	0	1	0	0	0	0	1
67	C	1	1	0	0	0	0	1
68	D	0	0	1	0	0	0	1
69	E	1	0	1	0	0	0	1
70	F	0	1	1	0	0	0	1
71	G	1	1	1	0	0	0	1
72	H	0	0	0	1	0	0	1
73	I	1	0	0	1	0	0	1
74	J	0	1	0	1	0	0	1
75	K	1	1	0	1	0	0	1
76	L	0	0	1	1	0	0	1
77	M	1	0	1	1	0	0	1
78	N	0	1	1	1	0	0	1
79	O	1	1	1	1	0	0	1
80	P	0	0	0	0	1	0	1
81	Q	1	0	0	0	1	0	1
82	R	0	1	0	0	1	0	1
83	S	1	1	0	0	1	0	1
84	T	0	0	1	0	1	0	1
85	U	1	0	1	0	1	0	1
86	V	0	1	1	0	1	0	1
87	W	1	1	1	0	1	0	1
88	X	0	0	0	1	1	0	1
89	Y	1	0	0	1	1	0	1
90	Z	0	1	0	1	1	0	1
91	[1	1	0	1	1	0	1
92	\	0	0	1	1	1	0	1
93]	1	0	1	1	1	0	1
94	^	0	1	1	1	1	0	1
95	_	1	1	1	1	1	0	1
96	`	0	0	0	0	0	1	1
97	a	1	0	0	0	0	1	1
98	b	0	1	0	0	0	1	1

99	c	1	1	0	0	0	1	1
100	d	0	0	1	0	0	1	1
101	e	1	0	1	0	0	1	1
102	f	0	1	1	0	0	1	1
103	g	1	1	1	0	0	1	1
104	h	0	0	0	1	0	1	1
105	i	1	0	0	1	0	1	1
106	j	0	1	0	1	0	1	1
107	k	1	1	0	1	0	1	1
108	l	0	0	1	1	0	1	1
109	m	1	0	1	1	0	1	1
110	n	0	1	1	1	0	1	1
111	o	1	1	1	1	0	1	1
112	p	0	0	0	0	1	1	1
113	q	1	0	0	0	1	1	1
114	r	0	1	0	0	1	1	1
115	s	1	1	0	0	1	1	1
116	t	0	0	1	0	1	1	1
117	u	1	0	1	0	1	1	1
118	v	0	1	1	0	1	1	1
119	w	1	1	1	0	1	1	1
120	x	0	0	0	1	1	1	1
121	y	1	0	0	1	1	1	1
122	z	0	1	0	1	1	1	1
123	{	1	1	0	1	1	1	1
124		0	0	1	1	1	1	1
125	}	1	0	1	1	1	1	1
126	~	0	1	1	1	1	1	1
127	"DEL"	1	1	1	1	1	1	1